


Flanschentreiber (Paar)

→ Zum Trennen der DIN-Flansche an Rohrleitungen beim Dichtungswechsel und bei Wartungsarbeiten

Flange spreaders (pair)


→ For separating DIN standard flanges on pipes when changing seals and during maintenance work



No.	 mm	Für Schrauben for screws			
306-S1	80–250	M16–M24	M24x1,5x110	24	5,6

Ersatzteile

Spare parts

No.		
306-1	1 Stck. Flanschentreiber 1 pc. flange spreader	2,8
306-1H	1 Stck. Haken 1 pc. hook	0,9
306-1SP	1 Stck. Spindel M24x1,5 mit Keil 1 pc. spindle M24x1,5 with wedge	0,6

Anwendungshinweis:

Die Flanschentreiber müssen immer paarweise und gegenüberliegend (180°) montiert werden. Durch gleichmäßiges und wechselseitiges Drehen der Spindeln werden die Keile eingepresst und die Flansche auseinandergetrieben. Um ein passgenaues Zusammenfügen der Flansche in ihre Ausgangslage zu erreichen, müssen die Spindeln wiederum gleichmäßig und wechselseitig zurückgedreht werden.

Application note:

Always use the flange-spreader in pairs and attach them to the opposite sides of the flange (180°). When the two spindles are turned alternately, the flanges will be separated from one another evenly. To guarantee a perfect fitting of the flanges in their original position, the spindles have to be turned back again alternately.