

Anwendungstabelle für Kugellager-Auszieher 60/61
Application table for ball bearing extractors no. 60/61

Auszieher No. Extractor no.	Hakensatz No. Set of pulling hooks no.	Für ISO-Kugellager-No. For ISO-ball bearings no.			
60-1	61-1	6000	6200		
		6001			
		6002			
	61-2	6003			
		6004	6201		
		6005	6202		
60-2	61-3	6006	6203	6300	
	61-4	6007	6204	6301	
		6008	6205	6302	
	61-5			6303	
				6304	
60-3	61-4				
	61-5		6206		
	61-6		6207	6305	
60-4	61-5	6009			
	61-7		6208	6306	
60-5	61-5	6010			
	61-6	6011			
		6012			
		61-8		6209	6307
				6210	6308
			6211	6309	6405
			6212	6310	6406
					6410



Kugellager-Auszieher Satz
Ball bearing extractor set

No.	Inhalt Content	Für ISO-Kugellager-No. For ISO-ball bearings no.	Kg
60-G	13-tlg.: No. 60-1 → 60-5 + No. 61-1 → 61-8 13 pcs.: no. 60-1 → 60-5 + no. 61-1 → 61-8	6000-6012 6200-6212 6300-6310 6403-6410	6,60